

SC4ARC Digital Band Plan Reference

June, 2016

	Mode		
Band	MFSK16	PSK31	RTTY
	USB	USB	LSB / USB+Rev
6	50,300.00	50,290.00	50,300.00
10	28,080.00	28,120.00	28,070 to 28,150
12	24,929.00	24,920.00	24,920 to 24,925
15	21,080.00	21,070.15	21,070 to 21,100
17	18,105.00	18,100.00	18,100.00
20	14,080.00	14,070.00	14,070 to 14,095
30	10,147.00	10,140.00	10,130 to 10,140
40	7,037.00	7,070.00	7,080.00
80	3580.00 to 3620.00	3580.00 to 3620.00	3580.00 to 3620.00
160	1,807.00	1,838.00	1,805.00

Digital modes are permitted in the RTTY and Data portions of the bands.
 There are no official frequency assignments for digital modes, just conventions.
 These frequencies are approximate – use them as a starting point for tuning.
 Use the waterfall to see what is actually happening and where.
 Pay attention to the band edges – there will be signals outside our licensed frequencies.